

2D Conditional averaging

Given 2D imaging data, select a reference pixel on which:

- Find all events where the signal is over a **threshold**.
- For each event:
 - Define the **peak** as the event maximum
 - Register and save the data centered in the peak with a fixed **window size**
 - Optionally, discard the event if any neighbour pixels at a distance lower than check argument have a higher value at the time the peak occurs.
 - Optionally, discard events with overlapping windows with preference for higher amplitude events.
- Return list of events and average over all events


Arguments

Name	Description
<code>dataset</code>	The 2D imaging data to process
<code>reference_pixel</code>	Pixel to base events on
<code>threshold</code>	Minimum signal value for events
<code>window_size</code>	Size of data window around peaks
<code>check_max</code>	Distance to check neighboring peaks
<code>single_counting</code>	Avoid overlapping event windows

Synthetic data


Simulated 5x5 data with 1000 blobs:

$l_x/l_y = 1/3$, $\theta = -\pi/4$, $v = 1$, $w = -1$




Result

Averaged output after conditional averaging:




Parameter estimation

Fit to a rotated ellipse to estimate sizes ℓ_x and ℓ_y and rotation θ



$$\ell_x = 1.57, \ell_y = 0.62, \theta = 0.78$$

Results: I mode



Results: L mode

